

Backflow Prevention Required

Published on City of Great Falls Montana (<http://www.greatfallsmt.net>)

Backflow Prevention Required

Backflow prevention is required on all fireline connections, sprinkler meters, pumped systems, high-rise buildings, hospitals, clinics, labs and any facility where there may be a possibility of backflow or backsiphonage which could contaminate our public water supply.

Source URL (retrieved on 01/27/2015 - 4:20pm):

<http://www.greatfallsmt.net/publicworks/backflow-prevention-required>